## FridgelQ

## **RFID Refrigerator Access Control**

Add refrigerators to your access control system with the retrofittable FridgelQ. Medical-grade refrigerators become prox card, fob, smartphone and keypad enabled. Easily set up user parameters via a web portal or smartphone. Enjoy enterprise wide management from anywhere while viewing audit trails and access attempts.

> Access Control Reader

**Externally Mounted Lock** Mechanism

**Optional** Remote Unlocking



### Retrofit:

Completed without interruption of hospital operations.



### Installation:

External mounting with no drilling or modifications to refrigerator.



### Compatibility:

Use existing prox cards or RFID devices. Compatible with 125KHz & 13.56MHz RFID Prox cards, fobs and stickers. Enroll hundreds of users.



### Set Up and Management:

Multiple levels of connectivity allows user to control via smartphone app, enterprise portal, or keypad.



WiFi/ethernet enabled for data and remote unlocking.



### Smartphone App:

MicroTraq, initializes and updates lock parameters and eliminates lock programming.



### Portal:

ProxTraq portal. (details on back page)



### Bluetooth enabled:

Mobile credentials, lock networking, and data.



### Lock Mechanism:

Durable rotor latch with proven reliability.



### Power:


12V DC powered.












### Controllable

- Manage access with mobile app
- Add, modify and remove locks, users and privileges
- View activity and history
- Conveniently manage hundreds of locks and users
- Security administration of enterprise from one portal
- Remote enrollment of RFID cards
- Assign access parameters for each lock, employee, group and location
- > Track activity and generate audit trails



# FridgelQ

**RFID Refrigerator Access Control** 



Bluetooth communication to lock unlock command change keypad codes switch operating modes update lock with updated parameters from portal  ADMINISTRATION commission & decommission locks into/out of service manage lock access parameters manage user access parameters enroll prox cards and assign to users select or complete prox card deletion enroll user for phone access upload audit trails, view & download set up and assign employee teams set up account organizations and sites no wiring or installed network equipment	Ticky Card  A 1 2 3 4 5 A  Second Class Card	MicroTraq admin Android only	ProxTraq portal	ProxTraq admin a Adroid & iOS	ProxTraq user app Adroid & iOS
unlock command  change keypad codes  switch operating modes  update lock with updated parameters from portal  ADMINISTRATION  commission & decommission locks into/out of service manage lock access parameters manage user access parameters enroll prox cards and assign to users select or complete prox card deletion enroll user for phone access upload audit trails, view & download set up and assign lock groups set up and assign employee teams set up account organizations and sites	LOCK FUNCTIONS AND COMMANDS				
change keypad codes  switch operating modes  update lock with updated parameters from portal  ADMINISTRATION  commission & decommission locks into/out of service  manage lock access parameters  manage user access parameters  enroll prox cards and assign to users  select or complete prox card deletion  enroll user for phone access  upload audit trails, view & download  set up and assign lock groups  set up and assign employee teams  set up account organizations and sites	Bluetooth communication to lock	•		•	•
switch operating modes  update lock with updated parameters from portal  ADMINISTRATION  commission & decommission locks into/out of service manage lock access parameters manage user access parameters enroll prox cards and assign to users select or complete prox card deletion enroll user for phone access upload audit trails, view & download set up and assign lock groups set up and assign employee teams set up account organizations and sites	unlock command	•			•
update lock with updated parameters from portal  ADMINISTRATION  commission & decommission locks into/out of service manage lock access parameters manage user access parameters enroll prox cards and assign to users select or complete prox card deletion enroll user for phone access upload audit trails, view & download set up and assign lock groups set up and assign employee teams set up account organizations and sites	change keypad codes	•	•		
ADMINISTRATION  commission & decommission locks into/out of service  manage lock access parameters  manage user access parameters  enroll prox cards and assign to users  select or complete prox card deletion  enroll user for phone access  upload audit trails, view & download  set up and assign lock groups  set up and assign employee teams  set up account organizations and sites	switch operating modes	•	•		
commission & decommission locks into/out of service  manage lock access parameters  manage user access parameters  enroll prox cards and assign to users  select or complete prox card deletion  enroll user for phone access  upload audit trails, view & download  set up and assign lock groups  set up and assign employee teams  set up account organizations and sites	update lock with updated parameters from portal			•	
manage lock access parameters  manage user access parameters enroll prox cards and assign to users select or complete prox card deletion enroll user for phone access upload audit trails, view & download set up and assign lock groups set up and assign employee teams set up account organizations and sites	ADMINISTRATION				
manage user access parameters enroll prox cards and assign to users select or complete prox card deletion enroll user for phone access upload audit trails, view & download set up and assign lock groups set up and assign employee teams set up account organizations and sites	commission & decommission locks into/out of service	•		•	
enroll prox cards and assign to users  select or complete prox card deletion enroll user for phone access upload audit trails, view & download set up and assign lock groups set up and assign employee teams set up account organizations and sites	manage lock access parameters	•	•		
select or complete prox card deletion enroll user for phone access upload audit trails, view & download set up and assign lock groups set up and assign employee teams set up account organizations and sites	manage user access parameters		•		
enroll user for phone access  upload audit trails, view & download  set up and assign lock groups  set up and assign employee teams  set up account organizations and sites	enroll prox cards and assign to users	•	•		
upload audit trails, view & download  set up and assign lock groups  set up and assign employee teams  set up account organizations and sites	select or complete prox card deletion	•	•		
set up and assign lock groups set up and assign employee teams set up account organizations and sites	enroll user for phone access		•		
set up and assign employee teams set up account organizations and sites	upload audit trails, view & download	•	•		
set up account organizations and sites	set up and assign lock groups		•		
	set up and assign employee teams				
no wiring or installed network equipment	set up account organizations and sites		•		
	no wiring or installed network equipment	•	•	•	

