

KnexIQ™

Wireless authentication reader & latch control module



Boost your access control systems IQ by making any lock an intelligent lock. With the addition of a **KnexIQ** module, latches and door strikes become prox card, fob, smartphone and keypad enabled.

Easily set up user parameters via a web portal or smartphone.

Enjoy enterprise wide management from anywhere while viewing audit trails and access attempts.



Latch mechanisms controlled:

Southco, HES, Adams Rite and other industry standard latches and door strikes.



Compatibility:

Compatible with 125KHz & 13.56MHz RFID Prox cards, fobs and stickers. Use existing prox cards or RFID devices. Enroll hundreds of users.



Set Up and Management:

Multiple levels of connectivity allows user to control via keypad, smartphone app, or enterprise portal.



Installation:

Externally mounted to enclosures & doors.



Portal:

ProxTraq or MobileTraq. (details on back page)



Power:

12 or 24 VDC powered or battery operation.



Smartphone App:

ProxTraq, initializes and updates lock parameters and eliminates device programming.



Power conservation:

Low power sleep mode extends battery life.




www.triteqlock.com



sales@triteqlock.com



Lock management via ProxTraq and cloud database:




Remote administration:

- ▶ Manage locks
- ▶ Manage users
- ▶ View audit trails

Controllable

- ▶ Manage access with mobile app
- ▶ Add, modify and remove locks, users and privileges
- ▶ View activity and history
- ▶ Conveniently manage hundreds of locks and users
- ▶ Security administration of enterprise from one portal
- ▶ Remote enrollment of RFID cards
- ▶ Assign access parameters for each lock, employee, group and location
- ▶ Track activity and generate audit trails



	MicroTraq admin app Android only	ProxTraq portal	ProxTraq admin app Android & iOS	ProxTraq user app Android & iOS	MobileTraq portal	MobileTraq user app Android & iOS	MobileTraq admin app Android & iOS
LOCK FUNCTIONS AND COMMANDS							
smartphone & tablet communication to lock	●		●	●		●	●
unlock command	●			●		●	●
change keypad codes	●	●					
switch operating modes	●	●					
update lock with updated parameters from portal			●				
locker locate & reserve						●	
locker rental & checkout						●	
item drop-off						●	
ADMINISTRATION							
commission & decommission locks into/out of service	●		●				●
manage lock access parameters	●	●			●		●
manage user access parameters		●					
enroll prox cards and assign to users	●	●					
select or complete prox card deletion	●	●					
enroll user for phone access		●			●		
upload audit trails, view & download	●	●					
set up and assign lock groups		●					
set up and assign employee teams		●					
set up account organizations and sites		●			●		
locker rental location & assignment					●		
locker rental billing					●		
rental & exchange membership					●		
pick-up & drop-off					●		
item exchange					●		
marketing, coupons, promotions					●		
no wiring or installed network equipment	●	●	●	●	●	●	●

